

ECOLAY®

INSTALLATION GUIDE

FOR USE WITH LAMINATE FLOORS

ECOLAY® should be used as an insulating/spot levelling layer between the floor to be laid and the sub-floor.

If laid on a concrete sub-floor a separate vapour barrier should be used.



1

Ensure floor is clean and flat*. Unroll at 90° to the direction of the floor, covering area to be laid. To assist laying, apply double-sided tape to the perimeter of the sub-floor.



2

Butt the edge of each roll tightly against the previous. Taping the joints between rows may assist in this process. Do not overlap the **ECOLAY®**.



3

Lay the flooring on top of the **ECOLAY®**, referring to the manufacturer's instructions.

CAUTION: ECOLAY® is combustible and should not be exposed to flame or other sources of ignition.

*A flat sub-floor means deviations of less than 2mm over 2.5m.



est. 1986
Engineering Underlay for rigid floors since 1995

"THE FIRST - THE BEST"

www.ecolay.co.uk

ECOLAY®

Underlay for laminate floors

EU ENTITY: Authorised Rep Compliance Ltd E-Mail: info@arccompliance.com

MANUFACTURED BY: Beacons Products Ltd, Unit 10, EFI Industrial Estate, Brecon Road, Merthyr Tydfil, UNITED KINGDOM CF47 8RB Telephone: +44 1685 350011