DAMP PROOF MEMBRANE (DPM) INSTALLATION GUIDE

FOR USE WITH FLOATING LAMINATE OR ENGINEERED FLOORS

• For areas with high sub-floor moisture level (above 4%)

- 1 Ensure the sub-floor is clean and flat*. To assist laying, apply double-sided tape to the perimeter of the sub-floor & tape the joints between each row.
- 2 If laid on a concrete sub-floor with sub-floor moisture level above 4% so the ACOUSTALAY® is to be used as a damp proof membrane, simply unroll on to a prepared sub-floor, at 90° to the direction of the floor, covering area to be laid. The first row should be laid with a minimum 20mm up the walls. Butt tightly together edge to edge. Do not overlap the ACOUSTALAY®. All rows, including the last, should be laid with a minimum 20mm up the wall. Carefully tape the joints between each row using waterproof tape.

If DPM overlap option selected, the first row of ACOUSTALAY® should be laid with the DPM overlap up the wall trimmed back to 20mm (minimum). Butt the next row of ACOUSTALAY® tightly against the first, overlapping the 200mm DPM overlap and using the integral adhesive strip (recommended for a complete seal).

All rows, including the last, should be laid with a minimum 20mm up the wall.

3 Lay the flooring on top of the **ACOUSTALAY®**, referring to the manufacturer's instructions.

Any surplus **ACOUSTALAY®** can be trimmed flush to the floor when installation is complete and will be concealed behind the new or refitted skirting, scotia/trim.

Suitable for use with underfloor heating.









CAUTION:

- * A flat sub-floor means deviations of less than 2mm over 2.5m.
- Acoustalay® is combustible and should not be exposed to flame or other sources of ignition.



est. 1986
Engineering Underlay for rigid floors since 1995
"THE FIRST – THE BEST"

www.acoustalay.co.uk



MANUFACTURED BY: Beacons Products Ltd, Unit 10, EFI Industrial Estate, Brecon Road, Merthyr Tydfil, UNITED KINGDOM CF47 8RB Telephone: +44 1685 350011